<u>Summary of Configuration Information and Changes</u>

Modem Login Page: 192.168.1.1

Modem Administrator User Name: admin

Modem Administrator Password: DSL password (Default is password, if you reset modem)

Where to go in Menu: [Wireless] > [Basic Settings]

Changes:

• [Channel]: Switch from [Auto] to Least Congested Channel (Usually 3,4, 8 or 9)


[Channel Width]: Set to [20Mhz]

1. Using an Ethernet cable plug into one of the yellow Local Area Network Ports at the back of the W9970 modem.



- 2. Connect to the Local Area Network on your computer.

 The network name should be NCF_XXXX or TP-Link_XXXXXXX. Your computer should indicate an Ethernet connection as opposed to wireless (symbols vary by Operating System).
- Open any Internet browser on your computer (Google Chrome, Mozilla Firefox, Safari or Internet Explorer) and connect to the modem by typing 192.168.1.1 in the address bar (as shown below).




4. Log in to the Administrative Account

Username: admin Password: DSL password (Default is password, if you reset modem)

Steps to Changing Wireless Channels on TP-Link W9970

5. From the [Status] page, navigate to [Basic Settings] Under the [Wireless] menu option on the left.



- 6. On the [Wireless Basic Settings] page, make the following changes:
 - [Channel:] change from [Auto] to channel with the least interference as determined by your wireless interference tests.
 - [Channel Width:] change from [Auto] to 20mhz

Notes:

Wireless channels shouldn't have to be changed often (more than once every 6-12 months). If
you find yourself making these changes too frequently, you may have to invest in a mid to high
end router with additional channels on the 5Ghz frequency. Contact NCF for
recommendations if needed.